

FIG. 1




FIG. 2




FIG. 3




FIG. 4

The diagram illustrates a graphical user interface window titled "PRINTER DRIVER UI". The window contains two input fields: "PRINT PORT" with the text "\\Server1\printer2" and "PRINTER IP ADDRESS" which is currently empty. Below the "PRINTER IP ADDRESS" field is a button labeled "OBTAIN AUTOMATICALLY". At the bottom of the window are two buttons: "OK" and "Cancel". Reference numerals 201, 202, 203, 204, and 205 point to the input field for the print port, the input field for the IP address, the "OBTAIN AUTOMATICALLY" button, the "OK" button, and the "Cancel" button, respectively.

PRINTER DRIVER UI	
PRINT PORT	201 \\Server1\printer2
PRINTER IP ADDRESS	202
	203 OBTAIN AUTOMATICALLY
	204 OK
	205 Cancel